


## **Airflow Panel Damper Options**

 Air Stratification Positioning: To improve Upper Server cooling, position scoop of Hi-Plume fin towards source of air supply. To reduce Upper Server cooling, turn scoop of Hi-Plume fin away from source of air supply.





Individual Air Baffle: Baffles provide Low profile fit that Snap in & out.





3. **Opposed Blade Damper:** Opposed Blade Damper may be field mounted by rotting butterfly tab or using threaded screw to engage frame insert. Dampers adjusted from top surface to exact desired setting.







 Slide Damper: Slide damper mounts the same as OPD and adjusts from top surface.



